



## EXTERNAL LIGHT STRIP INSTALLATION GUIDE



Locate the RGB header on your ZOTAC GAMING graphics card. Plug the bundled 3-pin RGB header cable into the graphics card, then connect your LED light strip to the cable.

- RGB port color is red for easy identification. Available on select models
- Using a tool like a needle nose plier or similar tool (not included) may help with the plug connection
- Compatible with 5V 3-pin LED light strip (not included)



Download, install, and use the latest version of the ZOTAC GAMING FireStorm software to interface with the connected LED strip.

291-CN001-53ZTF